

How to Protect Your Pump and Keep It Longer

If liquid pumps are an important part of your process, you should make the investment to protect them from dry running conditions and flow disturbances

'Nothing can damage a liquid pump faster than the buildup of heat from dry running conditions.' By Don Lundberg



FAST FACTS

In today's complex and frequently rugged process plant environments, liquid pumps are often overworked and underprotected from adverse operating conditions. Many pumps run nearly non-stop 24 hours a day over multiple shifts. Poor operating conditions can reduce pump performance, require extra maintenance, shorten pump life and increase costs. Losing a pump unexpectedly can be an expensive or even dangerous problem in a chemical plant. The consequences of pump failure can range from the loss of product in sensitive pharmaceutical batch control applications to damage to nearby equipment from pressure buildup of material that isn't moving. There can even be safety hazards when a pump fails to shut down and literally burns up in the presence of combustible materials. It really pays to protect and care properly for pumps. Two common problems that negatively affect pumps are wet/dry conditions and flow disturbances, both of which are preventable. Nothing can damage a liquid pump faster than the buildup of heat from dry running conditions, which occur when liquid stops flowing into the line or pump. When liquid isn't there to provide cooling, heat can destroy a pump's bearings. If repair is even possible, it is going to be a very expensive proposition. For proper and efficient operation, a pump requires a stable upstream flow profile in the pipeline before liquid enters it. When elbows, valves or other pieces of equipment are installed too closely to a pump, they can create swirl and velocity profile distortion in the pipeline. These disturbances can result in excess noise and cavitation, resulting in reduced bearing life. Installing a point flow/level switch in a pump's process loop eliminates the damage caused by a pump running dry. Point flow/level switches are capable of detecting not only low flow but also dry running. This capability allows the control system or operator to take corrective measures before the pump bearings are overheated and fail.

If the chemical plant is short on real estate with confined and non-ideal pipe configurations, an elbow flow conditioner eliminates all upstream straight run requirements for pumps, compressors, flow meters and other critical process

How to Protect Your Pump and Keep It Longer

Published on Chem.Info (<http://www.chem.info>)

equipment. Tab-type flow conditioners have been successful in these applications. Other flow conditioning technology choices, including tube bundles, honeycombs and perforated plates, also can be considered depending upon the specifics of the application. The elbow flow conditioner's profile conditioning tabs produce rapid cross-stream mixing, forcing higher velocity regions to mix with lower velocity regions. The shape of the resultant velocity profile is "flat" and repeatable regardless of the close-coupled upstream flow disturbances. Incorporating anti-swirl mechanisms in the design eliminates the swirl typically seen exiting 90-degree elbows. The result is a flow stream that enters the pump in such a way that it maximizes the efficiency of its operation and reduces stress. In addition, the tapered design of the anti-swirl and profile conditioning tabs makes them immune to fouling or clogging. *Don Lundberg is senior engineer, Fluid Components International, 1755 La Costa Meadows Dr., San Marcos, CA 92078, which specializes in critical flow, level and temperature process instrumentation solutions. Questions about this article can be addressed to Lundberg at 760-744-6950. Additional information is available at www.fluidcomponents.com.*

Source URL (retrieved on 03/16/2014 - 2:46am):

http://www.chem.info/news/2006/08/how-protect-your-pump-and-keep-it-longer?qt-most_popular=1&qt-recent_content=0